

System Population Served	Monthly Routine TCR Samples	Number of Sites Required for TCR (1.5xTCR samples) ¹	Additional Sites for Disinfectant Residual Monitoring (0.25xTCR samples)	Total Number of Sites ²	Monthly Disinfection Residual (TCR + Additional)
25 to 1,000 ³	1	5 ¹	1	6 ²	2
1,001 to 2,500	2	5 ¹	1	6	3
2,501 to 3,300	3	5	1	6	4
3,301 to 4,100	4	6	1	7	5
4,101 to 4,900	5	8	2	10	7
4,901 to 5,800	6	9	2	11	8
5,801 to 6,700	7	11	2	13	9
6,701 to 7,600	8	12	2	14	10
7,601 to 8,500	9	14	3	17	12
8,501 to 12,900	10	15	3	18	13
12,901 to 17,200	15	23	4	27	19
17,201 to 21,500	20	30	5	35	25
21,501 to 25,000	25	38	7	45	32
25,001 to 33,000	30	45	8	53	38
33,001 to 41,000	40	60	10	70	50
41,001 to 50,000	50	75	13	88	63
50,001 to 59,000	60	90	15	105	75
59,000 to 70,000	70	105	18	123	88
70,001 to 83,000	80	120	20	140	100
83,001 to 96,000	90	135	23	158	113
96,001 to 130,000	100	150	25	175	125
130,001 to 220,000	120	180	30	210	150
220,001 to 320,000	150	225	38	263	188

¹ The minimum number of sites required for TCR is five (5).

² Small non-community water systems consisting of a single building having fewer than 5 taps on the plumbing system may have a minimum of three (3) sites for TCR & disinfectant residual monitoring.

³ Non-community ground water system serving 1,000 or less individuals may monitor quarterly.